

ELECTRIC TOOL PARTS LIST

■ CORDLESS KIT Model KC 18DL

2004 · 7 · 15 (E1)





ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS	
1		MODEL DS 18DMR CORDLESS DRIVER DRILL	1		
2		MODEL C 6DC2 CORDLESS CIRCULAR SAW	1		
3		MODEL CR 18DV CORDLESS RECIPROCATING SAW	1		
4		MODEL ET 18DM MULTI CHARGER	1		
5		MODEL UB 18D CORDLESS TORCH LIGHT	1		
6	325-518	BAG	1		
					$\overline{}$