


ELECTRIC TOOL PARTS LIST

■ CORDLESS IMPACT DRIVER
Model WH 18DBDL2

2016 • 09 • 20
(E1)



STANDARD ACCESSORIES

WH18DBDL2

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
501	329897	BATTERY COVER	1	
502	UC18YFSL	CHARGER (MODEL UC 18YFSL)	1	
503	370700	CASE ASS'Y	1	INCLUD.504-509 FOR USA.CAN
504	339210	COVER (A)	1	FOR USA.CAN
505	339212	CENTER LATCH	1	FOR USA.CAN
506	339211	HANDLE (A)	1	FOR USA.CAN
507	339213	CENTER KNOB	1	FOR USA.CAN
508	339215	SIDE KNOB	2	FOR USA.CAN
509	339214	SIDE LATCH	2	FOR USA.CAN

OPTIONAL ACCESSORIES

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
601	992671	+ DRIVER BIT (B) NO.2 50L	1	
602	992672	+ DRIVER BIT (B) NO.3 50L	1	
603	983006	+ DRIVER BIT NO.2, DOUBLE ENDED	1	
604	983011	+ DRIVER BIT NO.3, DOUBLE ENDED	1	
605	321823	DRILL CHUCK AND ADAPTER SET	1	INCLUD.606.607
606	303334	CHUCK WRENCH FOR 10VLB-D.10VLR-D	1	
607	307543	CHUCK ADAPTER	1	
608	306927	SILICONE RUBBER	1	
609	309922	GREASE (ATTOLUB MS NO.2) 500G	1	
610	325149	GREASE (MOLUB-ALLOY NO.777-1) 75G	1	