



MODEL
WH18DDX

ITEM NO	ITEM CODE	DESCRIPTION	NO. USED	REMARKS
1	375143	GUIDE SLEEVE ASS'Y	1	INCLUD.2-5.9
2	330619	RETAINING RING	1	
3	330856	WASHER (D)	1	
4	331284	GUIDE SPRING (D)	1	
5	322717	GUIDE SLEEVE (D)	1	
6	337360	FRONT CAP	1	
7	375003	HAMMER CASE	1	
8	336639	WASHER (F)	1	
9	319535	STEEL BALL D3.5 (10 PCS.)	2	
10	374396	ANVIL (B)	1	
11	959154	STEEL BALL D5.556 (10 PCS.)	2	
12	375958	HAMMER	1	
13	959148	STEEL BALL D3.175 (10 PCS.)	28	
14	315978	WASHER (J)	1	
15	376565	HAMMER SPRING	1	
16	316172	WASHER (S)	1	
17	322740	STOPPER (A)	1	
18	375957	SPINDLE	1	
19	376564	IDLE GEAR SET (2 PCS.)	2	
20	324234	NEEDLE ROLLER (A)	2	
21	319911	WASHER (E)	1	
22	6901VV	BALL BEARING 6901VV	1	
23	331858	RING GEAR (A)	1	
24	334412	O-RING	1	
25	329517	DAMPER (A)	2	
26	374393	INNER COVER	1	
27	313687	TAPPING SCREW (W/FLANGE) D3X16 (BLACK)	9	
28		NAME PLATE	1	
29	376562	WIRING ASS'Y	1	INCLUD.31.32
30	374399	PUSHING BUTTON	1	
31	376362	DC-SPEED CONTROL SWITCH	1	
32	376361	BATTERY TERMINAL	1	
*33	376561M	HOUSING (A).(B) SET	1	FOR USA.CAN
*34	333353M	BATTERY BSL 1815 (USA.CAN)	2	INCLUD.502
		STANDARD ACCESSORIES		
*501		CHARGER (MODEL UC18YKSL)	1	
502	329897	BATTERY COVER	1	
503	992671	+ DRIVER BIT (B) NO.2 50L	1	
504	336642	CASE	1	
505	376358	HOOK SET	1	
		OPTIONAL ACCESSORIES		
601	992672	+ DRIVER BIT (B) NO.3 50L	1	
602	321823	DRILL CHUCK AND ADAPTER SET	1	INCLUD.603.604
603	307543	CHUCK ADAPTER	1	
604	987575	CHUCK WRENCH FOR 10VLB-D.10VLR-D	1	
605	309922	GREASE (ATTOLUB MS NO.2) 500G	1	
606	325149	GREASE (MOLUB-ALLOY NO.777-1) 75G	1	
607	306927	SILICONE RUBBER	1	
608	996177	NON-MAGNETIC HEX. SOCKET 8MM 65L	1	
609	985329	NON-MAGNETIC HEX. SOCKET 10MM 65L	1	
610	996178	NON-MAGNETIC HEX. SOCKET 12MM 65L	1	
611	996179	NON-MAGNETIC HEX. SOCKET 13MM 65L	1	
612	996180	NON-MAGNETIC HEX. SOCKET 14MM 65L	1	
613	996181	NON-MAGNETIC HEX. SOCKET 16MM 65L	1	
614	996182	NON-MAGNETIC HEX. SOCKET 17MM 65L	1	
615	996197	HEX. SOCKET (LONG) 21MMX166L	1	